

MULTIKABEL A FOR AKTIV MULTIKABELSYSTEM

Nordic Rental A/S bruger denne standard, men forholder sig retten til at ændre denne uden varsel eller ansvar for brugere der kopierer denne.

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	1	1	19	37	55	73	91	2	
	3	2	20	38	56	74	92	4	
	5	3	21	39	57	75	93	6	
	7	4	22	40	58	76	94	8	
	9	5	23	41	59	77	95	10	
	11	6	24	42	60	78	96	12	
	13	7	25	43	61	79	97	14	
	15	8	26	44	62	80	98	16	
	17	9	27	45	63	81	99	18	
	19	10	28	46	64	82	100	20	
	21	11	29	47	65	83	101	22	
	23	12	30	48	66	84	102	24	
	41	13	31	49	67	85	103	42	
	43	14	32	50	68	86	104	44	
	45	15	33	51	69	87	105	46	
	47	16	34	52	70	88	106	48	
	ASL A	17	35	53	71	89	107		
		18	36	54	72	90	108		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTIKABEL B FOR AKTIV MULTIKABELSYSTEM

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	25	1	19	37	55	73	91	26	
	27	2	20	38	56	74	92	28	
	29	3	21	39	57	75	93	30	
	31	4	22	40	58	76	94	32	
	33	5	23	41	59	77	95	34	
	35	6	24	42	60	78	96	36	
	37	7	25	43	61	79	97	38	
	39	8	26	44	62	80	98	40	
	SP 1	9	27	45	63	81	99	SP 2	
	AUX 1	10	28	46	64	82	100	AUX 2	
	AUX 3	11	29	47	65	83	101	AUX 4	
	AUX 5	12	30	48	66	84	102	AUX 6	
	AUX 7	13	31	49	67	85	103	AUX 8	
	AUX 9	14	32	50	68	86	104	AUX 10	
	AUX 11	15	33	51	69	87	105	AUX 12	
	AUX 13	16	34	52	70	88	106	AUX 14	
	AUX 15	17	35	53	71	89	107	AUX 16	
		18	36	54	72	90	108		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTIKABEL FOR BALANCEREDE EQ-INSERTS PANEL A

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	S 1	1	19	37	55	73	91	S 2	
	S 3	2	20	38	56	74	92	S 4	
	S 5	3	21	39	57	75	93	S 6	
	S 7	4	22	40	58	76	94	S 8	
	S 9	5	23	41	59	77	95		
	S 11	6	24	42	60	78	96	S 10	
	R 1	7	25	43	61	79	97	S 12	
	R 3	8	26	44	62	80	98	R 2	
	R 5	9	27	45	63	81	99	R 4	
	R 7	10	28	46	64	82	100	R 6	
	R 9	11	29	47	65	83	101	R 8	
	R 11	12	30	48	66	84	102	R 10	
		13	31	49	67	85	103	R 12	
		14	32	50	68	86	104		
		15	33	51	69	87	105		
		16	34	52	70	88	106		
		17	35	53	71	89	107		
		18	36	54	72	90	108		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTIKABEL FOR BALANCEREDE EQ-INSERTS PANEL A

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	S 1	1	19	37	55	73	91	S 2	
	S 3	2	20	38	56	74	92	S 4	
	S 5	3	21	39	57	75	93	S 6	
	S 7	4	22	40	58	76	94	S 8	
	S 9	5	23	41	59	77	95		
	S 11	6	24	42	60	78	96	S 10	
	R 1	7	25	43	61	79	97	S 12	
	R 3	8	26	44	62	80	98	R 2	
	R 5	9	27	45	63	81	99	R 4	
	R 7	10	28	46	64	82	100	R 6	
	R 9	11	29	47	65	83	101	R 8	
	R 11	12	30	48	66	84	102	R 10	
		13	31	49	67	85	103	R 12	
		14	32	50	68	86	104		
		15	33	51	69	87	105		
		16	34	52	70	88	106		
		17	35	53	71	89	107		
		18	36	54	72	90	108		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTIKABEL FOR BALANCEREDE EQ-INSERTS-B

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	S 13	1	13	25	37	49	61	S 14	
	S 15	2	14	26	38	50	62	S 16	
	S 17	3	15	27	39	51	63	S 18	
	S 19	4	16	28	40	52	64	S 20	
	S 21	5	17	29	41	53	65	S 22	
	S 23	6	18	30	42	54	66	S 24	
	R 13	7	19	31	43	55	67	R 14	
	R 15	8	20	32	44	56	68	R 16	
	R 17	9	21	33	45	57	69	R 18	
	R 19	10	22	34	46	58	70	R 20	
	R 21	11	23	35	47	59	71	R 22	
	R 23	12	24	36	48	60	72	R 24	

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTIKABEL FOR BALANCEREDE EQ-INSERTS-A

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	S 1	1	13	25	37	49	61	S 2	
	S 3	2	14	26	38	50	62	S 4	
	S 5	3	15	27	39	51	63	S 6	
	S 7	4	16	28	40	52	64	S 8	
	S 9	5	17	29	41	53	65	S 10	
	S 11	6	18	30	42	54	66	S 12	
	R 1	7	19	31	43	55	67	R 2	
	R 3	8	20	32	44	56	68	R 4	
	R 5	9	21	33	45	57	69	R 6	
	R 7	10	22	34	46	58	70	R 8	
	R 9	11	23	35	47	59	71	R 10	
	R 11	12	24	36	48	60	72	R 12	

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTISTIKFORBINDELSER FOR EFFEKTSKAB

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	S 1	1	19	37	55	73	91	S 2	
	S 3	2	20	38	56	74	92	S 4	
	S 5	3	21	39	57	75	93	S 6	
	S 7	4	22	40	58	76	94	S 8	
		5	23	41	59	77	95		
	1 L	6	24	42	60	78	96	1 R	
	2 L	7	25	43	61	79	97	2 R	
	3L	8	26	44	62	80	98	3 R	
	4 L	9	27	45	63	81	99	4 R	
	5 L	10	28	46	64	82	100	5 R	
	6 L	11	29	47	65	83	101	6 R	
	7 L	12	30	48	66	84	102	7 R	
	8 L	13	31	49	67	85	103	8 R	
		14	32	50	68	86	104		
		15	33	51	69	87	105		
		16	34	52	70	88	106		
		17	35	53	71	89	107		
		18	36	54	72	90	108		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

MULTIKABEL FOR EQ-INSERTS

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	S 1	1	19	37	55	73	91	S 2	
	S 3	2	20	38	56	74	92	S 4	
	S 5	3	21	39	57	75	93	S 6	
	S 7	4	22	40	58	76	94	S 8	
	S 9	5	23	41	59	77	95		
	S 11	6	24	42	60	78	96	S 10	
	R 1	7	25	43	61	79	97	S 12	
	R 3	8	26	44	62	80	98	R 2	
	R 5	9	27	45	63	81	99	R 4	
	R 7	10	28	46	64	82	100	R 6	
	R 9	11	29	47	65	83	101	R 8	
	R 11	12	30	48	66	84	102	R 10	
	S 13	13	31	49	67	85	103	R 12	
	S 15	14	32	50	68	86	104	S 14	
	S 17	15	33	51	69	87	105	S 16	
	R 13	16	34	52	70	88	106	R 14	
	R 15	17	35	53	71	89	107	R 16	
	R 17	18	36	54	72	90	108		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

Multikabel mellem mixerpult og X.overskab

Standard fra december 2000

FARVE/N R	KANAL	X	L	R	X	L	R	KANAL	FARVE/N R
1	MIX L	1	8	1	2	2	3	MIX R	2
				5	2	9	6		
3	DAT PB L	2	9	1	2	3	3	DAT PB R	4
				6	3	0	7		
5	CD PB L	3	1	1	2	3	3	CD PB R	6
			0	7	4	1	8		
7	MD PB L	4	1	1	2	3	3	MD PB R	8
			1	8	5	2	9		
9	CC PB L	5	1	1	2	3	4	CC PB R	10
			2	9	6	3	0		
11	RECOR D L	6	1	2	2	3	4	RECOR D R	12
			3	0	7	4	1		
		7	1	2	2	3	4		
			4	1	8	5	2		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3

Multistik for returkabel

FARVE	KANAL	X	L	R	X	L	R	KANAL	FARVE
	LEFT VLF	1	8	15	22	29	36	LEFT LF	
	LEFT HF	2	9	16	23	30	37	LEFT VHF	
	RIGHT VLF	3	10	17	24	31	38	RIGHT LF	
	RIGHT HF	4	11	18	25	32	39	RIGHT VHF	
	ASL A	5	12	19	26	33	40	ASL B	
	SUB A	6	13	20	27	34	41	SUB B	
		7	14	21	28	35	42		

X= XLR ben 1, L= XLR ben 2, R= XLR ben 3